



Armpad Sliding



Armpad Adjustment



Lumbar Adjustment



Armpad Sliding



Armrest Expand



Helmond user guide



Lumbar Adjustment




Tension Adjustment



Sliding Adjustment

Gaslift Adjustment



Locking Adjustment