Oosterhout NPR 1813 - NET (User Guide)

Date	10-8-2020
Revision	00

Use Guide for Oosterhout NPR 1813 - NET



Lumbar Support Adjustment

Lumbar support adjustment procedure

Pull or push the lumbar support upwards or downwards to find the required position.



Seat Depth Adjustment

Seat depth adjustment procedure

Pull out the seat cover right lever and glide forwards or backwards.



Armpad Slide Adjustment

Armpad sliding procedure Push the armpad button and pull forwards, backwards, in and out to find the required position.



Armpad Rotate Adjustment

Armpad sliding procedure Push the armpad button and push round to find the required position.



Back Tilting

Locking procedure Find the required position and push the left lever downwards.

Unlocking procedure Pull the left lever upwards and give pressure on the backrest.



Armrest Height AdjustmentHeight adjustment procedure
Pull the lever upwards and
find the required position.

Armrest Expand Adjustment

Expand adjustment procedure Push the lever down and find the required position - pull the lever up to lock.



Chair Height Adjustment

Height adjustment procedure Pull the right lever and find the required position